

DOCTOR BLADE EDGE GUARD INSTALLATION GUIDE

1. When working with doctor blades, always follow your company's safety rules regarding appropriate personal protection equipment (i.e. approved cut-resistant gloves) and procedures for safe handling of doctor blades.
2. Provide adequate work spaces, clamps, supports, etc. so that blade holders are not likely to fall or move while being worked on.
3. Doctor blade edge guards are to be installed on the doctor blade after the blade has been installed in the blade holder. Do not try to put an edge guard on a doctor blade that is not fully installed in the blade holder.
4. Starting at one end of the doctor blade, slip the edge guard over the doctor blade's working edge. Carefully guide the edge guard on the blade while working toward the other end of the doctor blade.
5. If desired, or to prevent the edge guard from falling off the doctor blade, apply strips of tape between the edge guard and blade holder at 18" intervals along the length of the blade holder.

